

A “o” denotes a point outside of accuracy/precision/safety precautions.

Topic	Accuracy/Precision	Safety
General	<ul style="list-style-type: none"> ✓ Always take preliminary readings. ✓ Measure t thrice and take the average. ✓ Remove all other sources of _____ (sound/light/etc) before conducting the experiment, to reduce systematic/random error. (circuits e.g.) (sound e.g.) 	
Nuclear	<ul style="list-style-type: none"> ✓ Preliminary readings. E.g. Determine the range of distances d and thicknesses t of front plates that will give a measurable difference in the count rate. ✓ Repeat the measurements for C_b and C_T thrice and take the average. ✓ Measure the background count rate C_b and subtract it from the total count rate C_T, to obtain the count rate $C = C_T - C_b$ of the sample. 	<ul style="list-style-type: none"> ✓ The source is handled with a pair of tongs, to prevent contact with the radioactive material. ✓ The source is stored in a lead lined box when not in use, to prevent contact with the radioactive material. ✓ Cordon off the area with tape and put up a warning sign, to prevent others from being exposed to radioactive material. ✗ Avoid pointing the source at people. ✗ Do not look directly at the source. ✗ Protective clothing, lead suits, lead gloves, goggles.
Thermal		<ul style="list-style-type: none"> ✓ Wear heat insulating gloves. ✓ Avoid touching the hot objects.

Waves

- Sound
 - ✓ Conduct the experiment in a soundproofed room, to minimise random error due to environmental noise.

- Light
 - ✓ Do not look directly at the light source, or point it directly at anyone.
 - ✓ Wear a pair of laser safety glasses (or shades for non-lasers) to protect the eyes.
 - ✓ Wear heat insulating gloves when moving the hot light source.

- Sound
 - ✓ Wear ear muffs to prevent hearing damage.
 - ✓ Switch on the sound source for a short period of time; turn it off when the apparatus is not in use.


Mechanics

- ✓ Explain clearly how to find the frequency of vibration f .

Starting with the highest available frequency, the frequency of strobing is gradually reduced till the vibrating object appears stationary. Record the frequency of vibration f as the frequency of strobing.

- ✓ Explain clearly how to use a pair of photogates with an electronic timer to obtain the time taken t .

The object is projected so that it passes through both photogates. Record the times at which it passes through each gate as t_1 and t_2 . Calculate the time taken $t = t_2 - t_1$.




When the distance between the gates is small, the average velocity \approx instantaneous velocity.

- Water/oil
 - ✓ Mop up any spillage of oil/water to avoid injuries due to falling.
- Load
 - ✓ Wear safety boots to reduce possible injuries to your feet.
- Moving parts
 - ✓ Avoid the moving blades of the fan using a safety screen. Switch off the fan when the apparatus is not in use.
- Glass
 - ✓ Wear thick safety goggles and thick gloves to prevent injury when handling the glass.

E&M

- ✓ Preliminary readings. E.g. Determine the range of frequencies f of e.m.f. and cross sectional area of the coil X that lead to a measurable range of induced e.m.f. ϵ .
- ✓ Use an iron core to increase the e.m.f. induced.
- ✓ Detailed description on how to use the cathode ray oscilloscope (c.r.o.) to obtain raw data. E.g.
 1. Using the grid on the screen, measure the maximum vertical distance y occupied by a complete waveform. Multiply y by the scale indicated on the Y-gain to obtain the peak voltage V_0 .
 2. Using the grid on the screen, measure the horizontal distance x occupied by a complete waveform. Multiply x by the scale indicated on the time base to obtain the period T .

(The c.r.o. should be connected in parallel for the above.)
- ✓ Remove all other sources of alternating magnetic fields, which lead to systematic error, before starting the experiment.
- ✓ Connect a Hall probe to a Gaussmeter. Calibrate the probe using a magnetic field of known strength. Then, orient the hall probe till a maximum voltage reading V_0 is obtained. Repeat this a few times at different positions; the magnetic field is uniform if V_0 remains approximately constant.
- ✓ Wear rubber gloves.
- ✓ Switch off the power supply when the apparatus is not in use to avoid overheating the wire/coil/etc.
- ✓ Do not touch the coil because might be hot.
- ✗ Do not mention electric shocks when the current and voltage used are small.



- Specify which setting, d.c. or a.c., an ammeter or voltmeter should be used in.
- A c.r.o. can either be connected directly to an electrical circuit, or to a microphone.
- A signal generator is an a.c. source with variable frequency, amplitude, and waveform. It can be connected to a loudspeaker.





Table 1: Precautions.